

Y adapter cable correct set up.

To correctly connect the Y adapter cables to your miner please ensure you use 2 separate PCI-E cables per Y adapter. (See images below)



Do not connect the cables as shown in the picture below.

